


INDIRECT WASTE FLOOR DRAIN



1630

CAST IRON INDIRECT WASTE FLOOR DRAIN WITH DOME BOTTOM STRAINER AND BOTTOM OUTLET.

INSTALLATION INSTRUCTIONS



The Wade 1630 Indirect waste floor drain is for slab on grade construction. The 1630 drain is typically installed below equipment to accept condensate. The condensate piping is terminated above the top of the drain - the body sump captures the drip and contains splashing. The drain piping is first run to an elevation below the expected finish floor level. The piping must include a p-trap and the drain body is secured to the pipe with with any of three connections; No-Hub, Inside Caulk, or Push-On Ty-Seal. The type of connection must be specified upon ordering any Wade Drain. If the Ty-Seal connection is specified, apply Tyler Ty-Seal lubricant to the inside surfaces of the gasket and then firmly push the drain body onto the pipe until it contacts the pipe stop in the body. No-Hub outlets should be installed with Tyler or Anaco/Husky couplings and secured with a torque wrench to the manufacturers recommendations. Inside Caulk connections should follow standard industry practices. Once the body is connected to the pipe, the concrete slab is poured to an elevation level with the top of drain body. For finish floor installation such as tile, the top of the drain should extend above the structural slab the dimension of the thickness of the floor material. Care must be taken to protect the top during installation. Use either cardboard, tape or other protective materials.

Approval Date
Customer Approval
Job Location
Job Name
Dimensional Data (Inches/mm) are Subject to Manufacturers Tolerance and Change Without Notice.
Wade Division / Tyler Pipe Assumes No Responsibility For Superseded or Voided Data