
INDUSTRIAL FLOOR DRAIN



Wade Division / Tyler Pipe Assumes No Responsibility For Superseded or Voided Data

2080 SERIES

FABRICATED STEEL FLOOR / AREA DRAIN WITH DUCTILE IRON GRATE, INTEGRAL TRAP, BRASS CLEANOUT PLUG, SEDIMENT BUCKET AND SPIGOT SIDE OUTLET. **INSTALLATION INSTRUCTIONS**



The Wade 2080 is suitable for various floor construction methods - it is ideally suited for smooth finshed stained concrete floors or for exterior applications. The 2080 is typicall used in garages, maintenance areas, service bays and industrial locations. At the drain location, excavate an area of sufficient size to accept the drain body. Bracing may be required to level the top of the drain. No-Hub connections should be installed with Tyler or Anaco/Husky couplings and secured with a torque wrench to the manufacturers recommendations. Once the body is connected to the pipe, the concrete is poured to an elevation level with the top of the drain body. The top of the drain should be at the finish floor level or slightly below. If a finish floor is to be applied, the top of the drain should extend above the structural slab to a dimension of the thickness of the floor material.

Note: If the drain is to be installed into asphalt paved parking areas which will be subjected to vehicular traffic, the drain must be installed into a reinforced concrete pad of sufficient thickness to support the traffic. This pad must extend around the drain body two or three times the top diameter. This is to keep weight from transfering to the piping system.

Care must be taken to protect the top during installation. Use either cardboard, tape or other materials to protect the top during construction.