
SQUARE FLOOR DRAIN



2390-PG

CAST IRON SQUARE PARKING AREA FLOOR DRAIN WITH DUCTILE IRON SECURED GRATE, WIDE SUPPORT FLANGE AND BOTTOM OUTLET.

GRATE FREE AREA - 89.1 SQ.IN.



Cat. No.	Pipe Size	Wt. Lbs.	Suffix	Description	
2392-PG 2393-PG 2394-PG 2396-PG 2398-PG OUTLETS	2 (50) 3 (75) 4 (100) 6 (150) 8 (200)	96.0 96.0 97.0 97.0 98.0	8 27 39	FLAT SECONDARY STRAINER SEDIMENT BUCKET GALVANIZED IRON PARTS	
NH NO-HUB	ТҮ	TY-SEAL	IC	INSIDE CAULK	AutoCad.dwa

PARKING DECK DRAIN



Wade Division / Tyler Pipe Assumes No Responsibility For Superseded or Voided Data


Customer Approval

Subject to Manufacturers Tolerance and Change Without Notice. are Dimensional Data (Inches/mm)

2390-PG

CAST IRON PARKING DECK DRAIN WITH HEAVY DUTY SUPPORT FLANGE, DUCTILE IRON TRACTOR STYLE GRATE, CLAMPING COLLAR AND BOTTOM OUTLET.

INSTALLATION INSTRUCTIONS



The Wade 2390-PG Parking deck drains are for installations in precast construction. The wide heavy duty support flange allows for shallow core drilling or boxing out. The heavy duty flange provides maximum strength at the load bearing surface. At the predetermined location, the drain is set into the floor recess. If desired, anchors are predrilled and secured to the flange. The surrounding area is finished with the specified grout flush with the top of the drain. The drain piping is connected to the body outlet with with any of four connections; Threaded, No-Hub, Inside Caulk, or Push-On Ty-Seal. The type of connection must be specified upon ordering any Wade Drain. If the Ty-Seal connection is specified, apply Tyler Ty-Seal lubricant to the inside surfaces of the gasket and then firmly push the pipe into the gasket until it contacts the pipe stop in the body. No-Hub outlets should be installed with Tyler or Anaco/Husky couplings and secured with a torque wrench to the manufacturers recommendations. Threaded or Inside Caulk connections should follow standard industry practices. Care must be taken to protect the top during installation. Use either cardboard, tape or other protective materials.

Note: If the piping is to be connected to a sanitary sewer system, a P-Trap must be installed at the drain outlet.

AutoCad.dwg